

### Description

Semi-transparent transfer paper with high dimension stability and moisture resistance. Used for the application of die-cut or computer-cut letters and symbols

### Adhesive

Natural rubber, low adhesive strength

### Area of Use

The special composition of the adhesive enables problem-free transfer of die-cut or computer cut letters and symbols using dry bonding techniques. This transfer paper has been developed for special uses which require an extraordinary low adhesive power. Specially developed for the transfer of large format letters and symbols made of ORALITE® Reflective Films.

### Technical Data

<b>Thickness*</b> (film with adhesive)	4.25-mil
<b>Weight*</b> (film and adhesive)	68#
<b>Adhesive power</b> (FINAT TM-1, after 20 min, stainless steel)	Adhered to stainless steel: 0.46 lb/in
<b>Tensile strength</b> (DIN EN ISO 527)	Along: Min. 5.4 MPa Across: Min. 2.5 MPa
<b>Elongation at break</b> (DIN EN ISO 527)	13.5%
<b>Shelf life**</b>	6 months
<b>Application temperature</b>	> +50°F
<b>Available lengths</b>	300' (100-yard)
<b>Available widths</b> (in inches)	14, 24, 30, 40, 48

\*average \*\*in original packaging, at 68°F and at 50% relative humidity

### IMPORTANT NOTICE

All ORATAPE® products are subject to careful quality control throughout the manufacturing process and are warranted to be of merchantable quality and free from manufacturing defects. Published information concerning ORATAPE® products is based upon research which the Company believes to be reliable although such information does not constitute a warranty. Because of the variety of uses of ORATAPE® products and the continuing development of new applications, the purchaser should carefully consider the suitability and performance of the product for each intended use, and the purchaser shall assume all risks regarding such use.

All specifications are subject to change without prior notice.

WARNING: This product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

ORATAPE® is a registered trademark of ORAFOL Europe GmbH.



ORAFOL Americas – GA  
1100 Oracal Parkway  
Black Creek, GA 31308  
Phone: 888.672.2251

ORAFOL Americas – CT  
120 Darling Drive  
Avon, CT 06001  
Phone: 800.654.7570

ORAFOL Canada  
2831 Bristol Circle  
Oakville, Ontario L6H 6X5  
Phone: 888.727.3374

techsupport-americas@orafol.com – www.orafol.com