

General Information

ORALITE® GP 801 tapes exceed all the requirements of specification EN ISO 20471:2013 separate performance and is certified for 100* wash cycles at 60° C per ISO 6330 method 2A. These instructions must be followed in order to maintain EN ISO 20471:2013 compliance. Variations in the care process will change the product performance. It is the end user's responsibility to ensure that the care instructions are observed.

**Please note that GP 801 black/check is certified for 50 wash cycles*

ORALITE® GP 801 cleans as well at lower temperatures as it does at higher temperatures. To permit environmentally friendly washing, reduce cost, and extend the life of the garment, select the lowest washing temperature that will ensure adequate cleaning of the fabric.

It may be necessary to modify the care label of garments with ORALITE® GP 801 tape applied to ensure that the performance of the reflective tape is not compromised through improper care.

Recommended Care Symbols



Hand Washing

Hand washing can be done with a sponge, a soft fabric cloth or a soft brush with lukewarm water and a mild detergent. After washing, the tape must be rinsed with clean water.

Stubborn stains such as grease or tar may be spot cleaned with petrol, alcohol, naphtha or turpentine. After spot cleaning the tape must be hand washed as above and rinsed with water.

Household Washing

Washer: Standard household washing machine

Temperature: 30° to 60° C

Detergent: Household detergent. Use detergents with moderate pH levels. Avoid using detergents with high pH levels.

Setting: "Coloured clothing without pre-wash"

Bleaching

Do not bleach.

Drying

Household tumble dryer set to 50° ± 5° C for 20-30 minutes, including 5 minutes cooling period at end of drying cycle. Dry to "slightly humid". DO NOT OVER DRY!

Note: Length of drying time may increase due to larger loads.

Ironing

Do not use steam.

Use a cool or warm temperature setting.

Avoid direct contact of the tape when ironing, use a press cloth.

Chemical Cleaning / Dry Cleaning

Dry cleaning is not recommended.

IMPORTANT NOTICE

All ORALITE® products are subject to careful quality control throughout the manufacturing process and are warranted to be of merchantable quality and free from manufacturing defects. Published information concerning ORALITE® products is based upon research which the Company believes to be reliable although such information does not constitute a warranty. Because of the variety of uses of ORALITE® products and the continuing development of new applications, the purchaser should carefully consider the suitability and performance of the product for each intended use, and the purchaser shall assume all risks regarding such use. All specifications are subject to change without prior notice.

ORALITE® is a registered trademark of ORAFOL Europe GmbH.